

# Changing the Filter - Benchtop

1. Pull off the spout.
2. To give more grip put the UltraStream on its side and take off the base plate off the base.
3. Grip the base and turn the filter anti-clockwise to unscrew the filter.
4. Put the new filter on the base and evenly screw the filter on clock-wise (don't over tighten).
5. Replace the cap, spout and base plate (make sure you align the blue tap with the groove in the base plate).
6. Flush the new filter for 5-10 minutes at 1 litre per minute.
7. To reinstall the filter, reverse the steps.



All water filters are dependent upon the quality of your source water, and will fail if excessive contaminants and sediment enter the filter.  
**Hence we can not guarantee 12 months' filter life.**

# How to Change Your Filter UnderSink

1. Pull out the Grey (or White) Converter with the blue hose in it. Using the John Guest Tool (you can also use finger nail or butter knife) push down the grey collet as you pull the blue tube (see handy tips p7 of the UltraStream manual).



*John guest tool*

2. Pull off the cap and base plate.
3. Grip the base and turn the filter anti-clockwise to unscrew the filter.
4. Put the new filter on the base and evenly screw the filter on clock-wise (don't over tighten).
5. Replace the cap and base plate.
6. Push in the Grey (or White) Converter with the blue hose into the new filter.
7. Flush the new filter for 10 minutes on a low flow rate (It's a good idea to check for any leaks).

